

TERMINATION

CENTRE CONTACT: SOLDER


FERRULE: 3.25mm A/F Crimp Hex

COAX CABLE ASSEMBLY

- 1. STRIP CABLE TO THE DIMENSIONS SHOWN ABOVE TAKING CARE NOT TO CUT INTO THE BRAID OR DIELECTRIC BEYOND THE REQUIRED POINTS.
- 2. CAREFULLY PLACE A PIECE OF HEAT SHRINK SLEEVE THEN FERRULE OVER THE CABLE JACKET, THEN TIN THE CENTER CONDUCTOR OF THE CABLE.



3. FAN THE BRAID OUTWARDS SO THAT WHEN THE TINNED CONDUCTOR IS PLACED INSIDE THE CONNECTOR BODY AND CORRECTLY SEATED IN POSITION ALL THE BRAID LAYS EXTERNAL TO THE CONNECTOR.



4. SOLDER THE CONDUCTOR TO THE CONTACT, MAKE SURE THE CAVITY IS CLEAR OF ANY DEBRIS AND FIT CAP INTO POSITION. SLIDE THE FERRULE DOWN CABLE AND OVER THE BRAID MAKING SURE IT SITS TIGHT AGAINST THE CONNECTOR BODY THEN CRIMP USING A 3.25MM A/F HEX, SLIDE HEAT SHRINK INTO PLACE AND SHRINK.



	ISSUE:	А	MMCX Right Angle Crimp Plug Cable Group - RG174
	DIM:	mm	
	SCALE:	9 / 1	
	PAGE:	1 OF 1	PART No:
	DATE:	23/05/09	277.121.044



THIS DOCUMENT AND INFORMATION CONTAINED HEREIN MAY NOT BE COBRA ELECTRONICS LIMITED.2009 COPIED, USED OR DISCLOSED BY WHOLE OR IN PART EXCEPT WITH 1 GREENACRES, BORDON custom cable assembly solutions THE WRITTEN PRIOR CONSENT OF COBRA ELECTRONICS LIMITED. HAMPSHIRE. GU35 0EX

FAX: +44 (0) 1420 479860